

1. The most important measurement is marked as #1 on our worksheet. This determines the length that we cut your rail for the lift. To obtain this measurement stand at the top of your stairs, extend your tape measure until it is laying on all the stair treads and the tip of the tape measure is touching the landing at the bottom of the steps. How many inches is it from the bottom landing to the top of the upper landing as show on our diagram? Put this measurement into the first block, Overall Length.

2. Next measure from the edge of the top step to the edge of the first step. Mark this in block 2.

3. Next, measure the width of your staircase and enter the measurement into block 3, marked Staircase Width.

4. If there is a wall or a door at the bottom of the steps as illustrated as 4 on the diagram below, please measure from the bottom step to the wall. Record the measurement in box #4 marked Bottom Clearance.

5. The last three measurements (5,6,7) will enable us to preset the seat angle of your lift at the factory. Please measure each according to the diagram and enter the measurement results in the appropriate boxes.

Looking up from the bottom of the staircase, which side of the staircase will the stairlift be mounted on?

Left  Right

1. Overall Length \_\_\_\_\_
2. Top stair to bottom stair \_\_\_\_\_
3. Staircase width \_\_\_\_\_
4. Bottom clearance \_\_\_\_\_
5. Rise of one step \_\_\_\_\_
6. Tread of one step \_\_\_\_\_
7. Diagonal \_\_\_\_\_

